

desta


Carbon Fiber Composite Stepstool

SCF-24


Top Step Height : 243mm / 9.6inch

Load Capacity : 150kg / 330lbs

Product Weight : 0.9kg / 1.98lbs



Name of each part



Thank you for your purchase.

This product is a "stepstool" made for working in high places. Read this User Guide before use to ensure correct assembly and use of the product. Store this guide in an easily accessible place for future reference. Please check the contents of the packaging, and if there is missing parts or damage, please contact the dealer where you purchased the product or our company.

- When somebody else use the product, please also let them understand how to use the product properly.
- For inquiries regarding the product, please contact the dealer where you purchased it or our company.

Safety Notice

Please read first

The product is made of carbon fiber reinforced resin.
The carbon fiber may appear white on the surface.
The properties of this material do not affect the use of the product.

Please read the "Safety Manual" carefully before use and use the product properly. Users have to follow this safety instruction, otherwise you may be seriously injured. We are not responsible for any accidents in case you don't follow this safety instruction.

The following marks classify and explain harm or damage that improper usage may cause.

 **DANGER** This symbol indicates that there is a high risk of death or serious injury.

 **WARNING** This symbol indicates that there is a risk of death or serious injury.

 **CAUTION** This mark indicates it may cause minor injury or property damage.

The following marks describe what must be observed.

 This mark indicates what you **MUST** do. |  This mark indicates what you **MUST NOT** do.

DANGER

 **The product may be highly conductive.**

 **Stand in the middle. Do not stand on tiptoe/one -leg.**
You may get possibility of falling or tipping over.

 **Do not lean forward and back.**
You may get possibility of falling or tipping over.

WARNING

 **Do not use for any purpose other than a stepstool.**
You may get possibility of injured and property damage.

 **Do not exceed the load capacity.**
It may tip over, fall, or deform.

 **Do not modify or disassemble.**
If this product is damaged, it may tip over or fall.

 **Do not use by children or anyone who cannot understand the Users manual or label.**
You may get possibility of injured and property damage.

 **Do not leave it in a condition where children can use it.**
You may get possibility of falling or tipping over.

⚠ WARNING



Before use, make sure if all parts are in good shape.
You may get possibility of injured and property damage.



Do not use it when deformed or damaged.
You may get possibility of injured and property damage.



Do not stand on the top panel more than two people at the same time.
You may get possibility of falling or tipping over.



Step up and down slowly and carefully .DO not jump.
You may get possibility of injured and property damage.



Watch your step carefully as you ascend and descend.
You may get possibility of falling or tipping over.



Do not climb/descend the product with your back towards it.
You may get possibility of falling or tipping over.



Be careful not to pinch fingers on moving or rotating parts.
You may get injured.



Do not use on unstable boxes nor other objects.
You may get possibility of falling or tipping over.



Do not use if you feel unwell or are ill.
You may not be able to maintain your physical balance and are at risk of falling or tumbling.

⚠ CAUTION



Do not use the product if this attached label is missing or unreadable.
You may get possibility of injured and property damage.



When lending this product to others, lend this user manual as well.



Do not open/close this product roughly, or do not drag or throw this product.
It can cause deformation or damage.

How to use

What to wear



• Please wear clothes that are easy to move in.

• Wear bare feet or non-slip footwear.

⚠ WARNING



Use wearing the appropriate clothing.
You may get possibility of injured and property damage.




Do not climb up and down with a load that could cause an imbalance.
You may get possibility of falling or tipping over.

How to use

Check Location

***Be sure to inspect the product before installation.**

For the inspection method, see P.17 "Pre-use checks".



Install the product in the following locations.

- **A flat and stable place**
- **A non-slippery place**
- **A place where the step is not buried.**
- **A bright place where you can clearly see your feet and surroundings.**
- **Places where there are no dangerous objects in the surroundings.**
- **A place where it can be used in a posture that does not interfere with work or climbing up and down**
- **Locations that are not exposed to rain or water.**
- **A place not subject to strong wind.**

*After installing, check for stability of the product.

*Do not use in unstable locations.

DANGER



Do not install near fire or in places with high temperatures.

WARNING



Do not use the product in unstable locations or conditions.

You may get possibility of falling or tipping over.



Do not install the product in a place with dangerous objects or obstacles around.

You may get possibility of falling or tipping over or property damage.



Do not use the product near doorways or other entrances.

There is a risk of tipping or falling when the door hits or someone passes by.



Do not use or leave the product in strong wind and rain.

You may get possibility of falling or tipping over or property damage.



Do not the product use in a slippery place.

You may get possibility of falling or tipping over.



Do not use the product in a folded.

You may get possibility of falling or tipping over or property damage.



If there is anything wrong with the product, stop using it without repairing it.

You may get possibility of falling or tipping over.




Check if there is no slippery matter such as grease, oil, mud, snow, water, or paint on the top board, and if so, wipe it off.


You may get possibility of injured and property damage.

How to open/close

1. Put your hand on the edge of the top board and release the top board from the hook.
2. When the top board (lattice pattern surface) is opened, the legs unfold.
3. Press down on the top board to lock it.



• Do not open or close as follows.



⚠ WARNING



Be careful not to pinch fingers on moving or rotating parts.

You may get injured.



Open/close carefully and slowly.


Your hand to be cut/injured in moving or rotating parts, resulting in deformation or damage.

How to use

How to climb and work

- Before use, check if there are no problems with the clothing and the installation location.
⇒ Refer to P.12 "What to wear" and P.13 "Check Location".
- Carefully ascend and descend with the front of your body facing the platform of the step.
- When working on a step, do not lean over the step.
- When riding on the step, make sure that your body is in the center of the top board.
- When moving the product, get off the step and move it.



- Take your time and carefully climb/descend.
- Be barefoot or wear non-slip footwear.



- Stand with your feet slightly apart to stand on the top step as illustrated in the left.



- When stepping on a top board, place your feet on it as shown in the figure below.




WARNING

-  **Do not hang a board between the two products and use it as a scaffold, etc.**
You may get possibility of falling or tipping over or property damage.
-  **Do not push or pull against walls or objects during use.**
You may get possibility of falling or tipping over.
-  **Ensure that the top panel is locked before use.**


About Strap Holes

You can attach a strap to the strap hole of this product and carry it over your shoulder.



Examples of commercially available straps

Camera Straps



Bag Straps



*Depending on the size and shape of the hook, it may not be attached to this product. Please check the hole size in advance.

⚠ CAUTION



Be careful not to get the strap caught when opening and closing the product.
You may get possibility of falling or tipping over or property damage.



Be careful not to get your feet caught in the straps when going up and down on the top board.
You may get possibility of falling or tipping over.



Be careful not to catch the strap anywhere when wearing the strap and carrying the product over the shoulder.
You may get possibility of falling or tipping over or property damage.

Pre-use checks

Checklist

***If the product has any of the following abnormalities, stop using it and contact us.**

 Deformation or cracking of any part of the product.

 Loose or missing pins, etc.

 Anti-slip cap comes off and wears out.

 Looseness of each part of this product such as hinges, top board and legs.

WARNING



Even if there is a problem with the product, You must not modify or repair it at your own discretion.

Even if it is repaired, the main body and metal fittings could be damaged, causing accidents such as overturning and falling.

Refer to P.18 "Trouble Shooting" if any abnormality is found.

How to care and store

How to care

〈How to clean〉

- Wipe off the dirt thoroughly with wet towel.
- When the stepladder is very dirty, wash it with water, and then wipe it dry.
- Oil-based stains should be removed with a cleaner or detergent, then wipe it off completely so that no cleaner or detergent remains.

〈How to remove dust from moving parts〉

- If the product does not open and close smoothly, check if there is mud, cement, or debris caught in the hinges and the moving parts of the legs, and remove it away.

How to store

In order to use this product safely when necessary, please store it after taking good care of it. Also, to prevent accidents and damage due to overturning, store in the following conditions.

- **Store indoors away from rain and direct sunlight.**
- **Store the product away from high temperature and high humidity.**

CAUTION



Do not place any objects on the top of this product.

It can cause deformation.



Do not leave this product outdoors.

It can cause deterioration or corrosion of each part.



Do not store this product near pesticides, cement, or lime.

Do not leave this product outdoors.

Malfunction?

Trouble Shooting

Problems	Where to check	What to Do
	Check the product is installed on a flat and stable place.	Move to a flat and stable location.
	Check there is no looseness or rattling in the joints.	
- Unstable when using.	Check there are no major bends or twists throughout.	If any, do not use the product (contact us).
	Check there are no cracks or deformations on the top board or legs.	
	Check for lost or worn-out anti-slip caps.	Replace the non-slip cap. (For replacement, please contact us.)
- The product does not open / close smoothly.	Check there is no dirt or debris stuck in the hinges, legs, or other moving parts.	Remove mud, debris, etc. from the product.
	Check that there is no deformation on the top board or legs.	
- The top panel cannot be locked.	Check for deformation of hinges and other movable parts.	If any, do not use the product (contact us).

Disposal

When disposing of the product, do not incinerate it.

It may cause danger to the surroundings, such as generation of organic gas.

When disposing of this product, please dispose of it in an appropriate manner according to the instructions of the local government.

Repair Contact

If you have any problems with this product, please contact us using the contact information on the back cover.

Hasegawa Kogyo Co., Ltd.

Edobori Center Bldg.14F 2-1-1 Edobori, Nishi-Ku, Osaka, 550-0002 Japan

www.hasegawaladders.com