

# WORK PLATFORM Instruction Manual

Thank you for purchasing our product. This product is a Work Platform designed to provide a stable base for working at heights. Please follow this instruction manual for safe use.

## Safety Precautions

Read these Safety Precautions carefully before use. Follow these instructions to prevent injury or property damage. The manufacturer is not responsible for accidents resulting from improper use or failure to follow these instructions.

### Hazard levels are defined as follows:

**⚠ DANGER** Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

**⚠ WARNING** Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

**⚠ CAUTION** Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury or property damage.

### Symbol Definitions:

**!** This mark indicates what you MUST do. **⊘** This mark indicates what you MUST NOT do.

### About the Pictograms

The following pictograms are used to quickly convey warnings:

- Risk of electric shock.
- Risk of pinching hand when operating.
- Risk of falling if Locking Brace are not locked.
- Risk of falling from loss of balance.
- [For Adjustable Legs and control levers.] Risk of fall or damage if unlocked Adjustable Leg retracts.

### ⚠ DANGER

**!** Be aware of power lines, people, and objects when setting up or carrying. Risk of electric shock or property damage.

**⊘** Do not stand on the edge of the platform, on tiptoes, or on one foot. Risk of falls and tip-overs.

**⊘** Do not overreach from the product. Risk of falls and tip-overs.

### ⚠ WARNING

**⊘** Use only as a work platform. Risk of injury or property damage.

## Proper Attire

### ⚠ WARNING

**!** Wear appropriate clothing for work platform. Risk of injury or property damage.

**⊘** Do not carry loads that can affect your balance. Risk of falls and tip-overs.

### ⚠ Beware of falls due to misuse or carelessness.

This manual contains usage instructions and safety precautions. Read this manual carefully before use. Keep this manual in a safe place for future reference. Check the package contents. If any parts are missing or damaged, please contact the retailer or our company.

- If you transfer or lend this product to a third party, always include this manual.
- For inquiries about this product, please contact the retailer or our company.

**!** Do not exceed maximum load capacity on Spec Label. Risk of falls, tip-overs, or product deformation.

**⊘** Do not modify or disassemble. Product failure can cause falls and tip-overs.

**⊘** Do not allow use by children or anyone unable to understand instructions. Risk of injury or property damage.

**⊘** Do not leave unattended where children can access. Risk of falls and tip-overs.

**!** Always inspect for any damage before use. Risk of injury or property damage.

**⊘** Do not use if damaged or deformed. Risk of injury or property damage.

**⊘** Never more than one person at a time. Risk of falls and tip-overs.

**⊘** Do not jump onto or off of the product. Risk of injury or property damage.

**!** Watch your step when climbing or descending. Risk of falls and tip-overs.

**⊘** Always face the product and use both hands. Risk of falls and tip-overs.

**⊘** Do not use if impaired or unwell. Loss of balance can cause falls and tip-overs.

**!** Beware of pinch points when opening and closing. Risk of injury.

**⊘** Do not place on boxes or unstable bases to gain height. Risk of falls and tip-overs.

### ⚠ CAUTION


**⊘** Do not use if labels are missing or illegible. Risk of injury or property damage.

**!** Always provide this manual if lending the product to others.


**⊘** Do not overtighten straps during transport. Risk of deformation or damage.

**⊘** Do not handle roughly (slam, drag, or throw). Risk of deformation or damage.

**!** Use two people to carry if difficult to move alone. Carry with the top plate facing down. Risk of injury or property damage.



## Names of Parts




## About the Labels

\*Please note that label designs may change from those shown without prior notice.

- The label number is printed on the bottom right of the label.
- The "O" in the label number is a revision number and will vary by label.

## For Adjustable Legs.



## Setup Location

\*Always inspect the product before setup. See "Pre-use Inspection".



### Set up in a location that is:

- Flat and stable
- Non-slip
- Firm ground where it will not become buried
- Well-lit
- Clear of hazards
- Sufficient clearance for work
- Dry
- Protected from wind

\*After setup, ensure it is stable and the Locking Brace is engaged with the Locking Pin.

\*If unstable, move to a safe location.


### ⚠ 警告

- ⊘** Do not use the product on an uneven or unstable surface. Risk of falls and tip-overs.
- ⊘** Do not use in areas with vibration. Risk of falls and tip-overs.
- ⊘** Do not set up near hazards or obstacles. Risk of falls, tip-overs, or property damage.
- ⊘** Do not use near doorways to avoid collisions. Risk of falls and tip-overs.
- ⊘** Do not use or leave in strong wind or rain. Risk of falls, tip-overs, or property damage.
- ⊘** Do not set up where the platform is not level. Risk of falls and tip-overs.
- ⊘** Do not use on slippery surfaces. Risk of falls and tip-overs.
- ⊘** Do not place objects on the platform to stand on. Risk of falls and tip-overs.
- ⊘** Never use when folded. Risk of falls, tip-overs, or property damage.
- !** If the product is damaged, stop use immediately. Do not attempt repairs. Risk of falls and tip-overs.
- !** Keep Platform clean from slippery substances (oil, mud, snow, etc.). Risk of injury or property damage.
- ⊘** Do not set up where the footing or surrounding area is not clearly visible. Risk of falls, tip-overs, or property damage.

## How to Use

### Setup and Folding

1. Lay the folded product on the ground with the Platform facing down.
2. Hold the leg steps and fully open the legs.
3. Securely engage all Locking Braces with the Locking Pins.
4. Slowly raise the Work Platform into its standing position.
5. Double-check that all Locking Braces are engaged.
6. To fold, reverse these steps.



### ⚠️WARNING

- Securely open and set up the legs. Risk of wobbling.
- Open and close slowly and carefully. Rough handling can cause deformation or damage.

### How to Use the Adjustable Legs (For Adjustable Models only)


1. Push up the Bottom control lever. [Unlocked]
2. Adjust the length of the Adjustable Leg by moving it up or down. Keep the lever held up (unlocked) while adjusting.
3. Release the lever to lock the Adjustable Leg in place. [Locked]

### ⚠️WARNING


- Adjust the legs to keep the platform and Steps level. Risk of falls and tip-overs.
- Do not handle adjustable section roughly. Risk of injury or property damage.
- Beware of pinch points in moving parts. Risk of injury.
- Ensure all Adjustable Legs are locked. Risk of falls and tip-overs.

### Climbing, Descending, and Working

- Climb and descend slowly and carefully.
- Wear non-slip footwear.
- As shown in the diagram, stand on the platform with feet slightly apart.



- Wear non-slip footwear, such as athletic shoes.
- When using for cleaning work, be careful not to splash the product with water.
- Face the climbing side of the product and climb/descend one step at a time.
- When working on the platform, do not overreach from the product.
- When standing on the platform, position your body in the center.
- Always get off the product to move it
- Place feet as shown in the diagram below.



### ⚠️WARNING

- Never use planks on the platforms to create a scaffold. Risk of falls, tip-overs, or property damage.
- Do not push or pull objects from the product. Risk of falls and tip-overs.
- Before climbing, ensure Locking Brace are locked. Risk of falls, tip-overs, or property damage.

## Pre-use Inspection

### Checklist Item

\*If any of the following issues are found, stop use immediately and contact us.

<b>Bent, twisted, or dented Side Rails or platform.</b> 	<b>Damaged, loose, deformed, worn, or severely corroded parts.</b> 
<b>Loose or missing rivets, screws, or pins.</b> 	<b>Loose or worn Anti-slip Caps.</b> 
<b>Wobbling or rattling of any part.</b> *Check by hand as shown. 	<b>All Leg Braces lock securely.</b> Check that all Leg Braces lock securely. If they cannot be locked securely, do not use the product.

### ⚠️WARNING

- If the product is damaged, never attempt to repair it yourself. Improper repairs can lead to product failure and serious accidents.

## Maintenance Instructions

Mud, dirty water, cement, lime, and seawater are very damaging. Always keep the ladder clean.

### ⚠️CAUTION

- Do not leave cleaners or detergents on the ladder. Risk of corrosion.

## Storage Instructions

For safe future use, clean the product thoroughly before storage. To prevent accidents or damage, store as follows:

- Store indoors, away from rain and direct sunlight.
- Store in a cool location.
- If the product is wet, dry it completely before storing.

### ⚠️CAUTION

- Do not place objects on the product. Risk of deformation.
- Do not leave the product outdoors. Risk of deterioration or corrosion.
- Do not store near chemicals, cement, or lime. Chemical reactions may cause corrosion.



## Troubleshooting

Symptom	What to Check	Solution
The product wobbles.	- Is the product on a flat, stable surface?	Move to a flat, stable surface.
	- Are the joints between the Side Rails and Steps loose or wobbly? - Are the joints between the Side Rails and Hinges loose or wobbly? - Is the product bent or twisted overall? - Are there any bends, dents, or deformations on the Side Rails or Steps?	If any issues are found, stop use and contact us.
	- Are the Anti-slip Caps loose, missing, or worn?	Replace the Anti-slip Caps. Contact us for replacements.
- Does not open / close smoothly. - Locking Braces will not lock securely.	- Is there any debris lodged in the Hinges? - Are the Locking Brace deformed? - Is the Lock Section damaged, deformed, or rusted? - Are the Locking Pins damaged, deformed, or missing? - Are the Side Rails or Hinges deformed?	Remove any debris.  If any issues are found, stop use and contact us.
	- Are the Hinges rusted?	If rusted, lubricate the moving parts. If heavily rusted, stop use and contact us.
[For Adjustable Models] - Adjustable Leg will not lock securely. - Adjustable Leg does not slide smoothly.	- Are the Adjustable Leg or locking mechanism damaged, eformed, or rusted? - Is there any debris (mud, cement, paint, etc.) on or in the Adjustable Leg or locking mechanism?	If any issues are found, stop use and contact us.  Remove any debris. If it cannot be removed, stop use and contact us.

**Contact for Repairs** For any issues with this product or for replacement parts, please contact us.

**Disposal** Dispose of this product in accordance with your local laws and regulations.

**Hasegawa Kogyo Co., Ltd.** Edobori Center Bldg 14F, 2-1-1 Edobori, Nishi-Ku, Osaka, 550-0002 Japan  
[www.hasegawaladders.com](http://www.hasegawaladders.com) [ info@hasegawaladders.com ]